

For all TEN-TEC rigs that use the same interface method and protocol as the Eagle Model 599, use the following file for OmniRig.

TenTec Eagle.ini

Place it in the program files location for the ini files for OmniRig.

e.g.

C:\Program Files\Afreet\OmniRig\Rigs

Run OmniRig and select the following:

Rig type = TenTec Eagle

Port = the comm port for the Eagle

Baud rate = 57600

Data bits = 8

Parity = None

Stop bits = 1

RTS = High

DTR = High

Poll int. ms = 500

(do not poll more often than 250ms, 500 is recommended)

Timeout, ms = 4000

Press OK

For programs using OmniRig, for the rig type, select "Omnirig".